


Solenoid coil acc. to VDE 0580

- With integrated amplifier electronics PD2
- Protection class IP 67



DESCRIPTION

Solenoid coil with integrated amplifier electronics. Protection class is IP67. The electronics are fix mounted on the solenoid coil. The construction corresponds to standard VDE 0580. The steel housing is zinc nickel coated.

FUNCTION

The electronics has a Pulse-Width-Modulated current output. The solenoid output can also be parameterised for switching solenoids. The parameterisation is carried out directly on the device by means of push-buttons and display, or by means of the parameterisation and diagnostics software „PASO“ of Wandfluh.

APPLICATION

Due to its water spray resistant execution, the solenoid coil is suitable for most diverse applications.

It can be used on all proportional valves with 19 mm, 23 mm resp. 31 mm armature tube diameters.

Easy connecting enables assembly and commissioning with conventional tools. All settings can be carried out easily and quickly.

TYPE CODE

M P - P 1 - - #

Metal housing square

Integrated amplifier electronics

Coil execution

Square 35 mm
Square 45 mm

S35/19x50
 S45/23x50

Square 60 mm
Square 60 mm

S60/31x72
 A60/31x72*

Connection cable
away from the solenoid

1-solenoid execution

Nominal voltage U_N

12 VDC
24 VDC

12
 24

Analogue input
CANopen acc. to DSP-408
with J1939

voltage / current (0...5V factory preset)

A1
 C1
 J1 (on request)

Design index (subject to change)

* only for proportional spool valve NG10

GENERAL SPECIFICATIONS

Connections	Connection cable	5 x 0,34 mm ² , Exterior coating PVC length = 1,5 m
	USB interface	via connection «Digital input» requires the Wandfluh USB adapter PD2
Dimensions	See drawing page 3	
Ambient temperature	-20...+85 °C	

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70


Казахстан (772)734-952-31

Amplifier with analogue interface


ELECTRICAL SPECIFICATIONS

Protection class	IP67 acc. to EN 60 529	Dither	Frequency adjustable 4...500 Hz
Supply voltage	8...32 V		Factory setting 80 Hz
Residual ripple	< +/-5 %		Level adjustable 0...400 mA
Fuse	low		Factory setting 180 mA
No-load current	approx. 20 mA	Temperature drift	<1 % at $\Delta T = 40^\circ\text{C}$
Max. current consumption	No-load current + 2,5 A per solenoid	Digital inputs	1 input high-active, no pull-up/down
Analogue input	1 input non-differential Voltage / current (switchable by means of parameter) 0...+/- 10V or 0/4...20mA		Switching threshold high 6...32 VDC Switching threshold low 0...1 VDC
Resolution	10-Bit		Usable as frequency input (frequency 5...5000 Hz) and as PWM input (automatic frequency recognition)
Input resistance	Voltage input >100 k Ω (Input current < 5 mA)	Ramps	Adjustable 0...500 s
	Load for current input = 124 Ω	USB interface	Via digital input
Stabilised output voltage	5 VDC max. load 20 mA	EMV Immunity Emission	Requires the Wandfluh USB adapter
<i>Solenoid current:</i>			
• Minimal current I_{\min}	Adjustable 0... I_{\max} mA Factory setting 30 mA		EN 61 000-6-2
• Maximal current I_{\max}	Adjustable I_{\min} ...2450 mA MP35/19x50...-12, Factory setting 1360 mA MP35/19x50...-24, Factory setting 680 mA MP45/23x50...-12, Factory setting 1490 mA MP45/23x50...-24, Factory setting 780 mA MPS60/31x72...-12, Factory setting 2290 mA MPA60/31x72...-12, Factory setting 2290 mA MPS60/31x72...-24, Factory setting 1140 mA MPA60/31x72...-24, Factory setting 1140 mA		EN 61 000-6-4

BLOCK DIAGRAM




ABMESSUNGEN



CONNECTOR ASSIGNMENT

Connection cable



- 1 = + VCC
- 2 = Command value
- 3 = Dig Inp
- 4 = Stab out
- 5 = GND

START-UP

Information regarding installation and commissioning are contained in the information leaflet supplied with the amplifier electronics and in the operating instructions.

Additional information can be found on our website:

Free-of-charge download:

- «PASO-PD2» Parameterisation software
- Operating instruction (*.pdf)

ADDITIONAL INFORMATION

Wandfluß electronics general

Wandfluß documentation-register 1.13

Proportional spool valve

register 1.10

Proportional pressure valves

register 2.3

Proportional flow control valves

register 2.6

ACCESSORIES

USB-adapter PD2

Article no. 726.9900


incl. USB-cable type A-B, 1,8 m
(for parameterisation via PASO)

PARAMETER SETTINGS

The PD2 electronics have push-buttons and a 7 segment display which enable setting the most important parameters. In addition, the digital input can be used as a communication interface, through which, by means of the parameterisation software „PASO-PD2“, the complete parameterisation and diagnostics can be carried out. For this, the Wandfluß USB-PD2 adapter is required. (not included in the delivery)

Attention: During the communication, the digital input cannot be used.

FUNCTION DESCRIPTION



PD2-AMPLIFIER WITH ANALOGUE INTERFACE

Command value scaling

The command value can be applied as a voltage, current, digital, frequency or PWM signal. The scaling takes place via the parameter "Interface". Furthermore, the command value can be monitored for a cable break. A dead band can also be set.

Fixed command value

There is 1 fixed command value available, which can be selected via the digital input. This function has to be configured before in PASO.

Ramp generator


Two linear ramps for up and down are available which can be adjusted separately.

Valve type

Adjustment possibilities: switching solenoid or proportional solenoid.


Mode of operation „Command value unipolar/bipolar (1-Sol)

Dependent on a command value signal (voltage, current, digital, frequency or PWM), the solenoid is driven (e.g. 0...10V correspond to 0...100 % command value, 0...+100 % command value correspond to Imin...Imax solenoid driver)




CONNECTION EXAMPLES


Supply voltage



Digital input as function input



Digital input as USB interface



Signal recording

Furthermore, the „PD2“ amplifier electronics have a signal recording function. This, by means of PASO, enables the recording of various system signals, such as command value, solenoid current, etc., which can be represented on a common time axis.

Solenoid driver

A Pulse-Width-Modulated current output is available. A dither signal is superimposed, whereby the dither frequency and the dither level are separately adjustable. The minimum (Imin) and maximum (Imax) current can be adjusted. The solenoid output can also be configured as switching solenoid output. In this case, a power reduction can be adjusted.

Optimisation of characteristic curve

An adjustable characteristic curve „Command value input – solenoid current output“ enables an optimised (e.g. linearised) characteristic of the hydraulic system.


Channel enabling

As per factory setting, the device is enabled („on“). This „enable channel“ can be set to „on“, „off“ or „external“ (digital input) via PASO or via menu item.


Hints:

Digital input: if not wired, the state of the digital input is not defined
 Analogue input: if not wired, the voltage input will read 1.11 V constantly.


Analogue input with potentiometer



Analogue input current with external current source



Analogue input voltage with external voltage source




Amplifier with CANopen interface


ELECTRICAL SPECIFICATIONS

Protection class	IP67 acc. to EN 60 529	Dither	Frequency adjustable 4...500 Hz
Supply voltage	8...32 V		Factory setting 80 Hz
Residual ripple	< +/-5 %		Level adjustable 0...400 mA
Fuse	low		Factory setting 180 mA
No-load current	approx. 20 mA		<1 % at $\Delta T = 40^\circ\text{C}$
Max. current consumption	No-load current + 2,5 A per solenoid	Temperature drift	1 input high-active, no pull-up/down
		Digital inputs	Switching threshold high 6...32 VDC
			Switching threshold low 0...1 VDC
<i>Solenoid current:</i>			Usable as frequency input
• Minimal current I_{\min}	Adjustable 0... I_{\max} mA Factory setting 30 mA		(frequency 5...5000 Hz) and as PWM input (automatic frequency recognition)
• Maximal current I_{\max}	Adjustable I_{\min} ...2450 mA MP35/19x50...-12, Factory setting 1360 mA MP35/19x50...-24, Factory setting 680 mA MP45/23x50...-12, Factory setting 1490 mA MP45/23x50...-24, Factory setting 780 mA MPS60/31x72...-12, Factory setting 2290 mA MPA60/31x72...-12, Factory setting 2290 mA MPS60/31x72...-24, Factory setting 1140 mA MPA60/31x72...-24, Factory setting 1140 mA	USB interface	Via digital input Requires the Wandfluh USB adapter
		EMV	EN 61 000-6-2
		Immunity	EN 61 000-6-4
		Emission	

BLOCK DIAGRAM




DIMENSIONS



ANSCHLUSSBELEGUNG

Anschlusskabel



- 1 = + VCC
- 2 = CAN-Low
- 3 = Dig Inp
- 4 = CAN-High
- 5 = GND

START-UP

Information regarding installation and commissioning are contained in the information leaflet supplied with the amplifier electronics and in the operating instructions.

Additional information can be found on our website:

Free-of-charge download:

- «PASO-PD2» Parameterisation software
- Operating instruction (*.pdf)

ADDITIONAL INFORMATION

Wandfluh electronics general

Wandfluh documentation-register 1.13

Proportional spool valve
Proportional pressure valves
Proportional flow control valves

register 1.10
register 2.3
register 2.6

ACCESSORIES

USB-adapter PD2
incl. USB-cable type A-B, 1,8 m
(for parameterisation via PASO)


Article no. 726.9900

PARAMETER SETTINGS

The PD2 electronics have push-buttons and a 7 segment display which enable setting the most important parameters. In addition, the digital input can be used as a communication interface, through which, by means of the parameterisation software „PASO-PD2“, the complete parameterisation and diagnostics can be carried out. For this, the Wandfluh USB-PD2 adapter is required. (not included in the delivery)

Attention: During the communication, the digital input cannot be used.

FUNCTION DESCRIPTION



Command value scaling

The command value can be applied as a CAN-bus, digital, frequency or PWM signal. The scaling takes place via the parameter „Interface“. Furthermore, the command value can be monitored for a cable break. A dead band can also be set.

Fixed command value

There is 1 fixed command value available, which can be selected via the digital input. This function has to be configurated before in PASO.

Ramp generator


Two linear ramps for up and down are available which can be adjusted separately.

Valve type

Adjustment possibilities: switching solenoid or proportional solenoid.

Mode of operation „Command value unipolar/bipolar (1-Sol)

Dependent on a command value signal (CAN-bus, digital, frequency or PWM), the solenoid is driven (e.g. 0...16383 CAN-command correspond to 0...100 % command value, 0...+100 % command value correspond to Imin...Imax solenoid driver)

**Signal recording**

Furthermore, the „PD2“ amplifier electronics have a signal recording function. This, by means of PASO, enables the recording of various system signals, such as command value, solenoid current, etc., which can be represented on a common time axis.

Solenoid driver

A Pulse-Width-Modulated current output is available. A dither signal is superimposed, whereby the dither frequency and the dither level are separately adjustable. The minimum (Imin) and maximum (Imax) current can be adjusted. The solenoid output can also be configurated as switching solenoid output. In this case, a power reduction can be adjusted.

Optimisation of characteristic curve




An adjustable characteristic curve „Command value input – solenoid current output“ enables an optimised (e.g. linearised) characteristic of the hydraulic system.

Channel enabling

As per factory setting, the device can be enabled via CAN-bus. This „enable channel“ can be set to „bus“, „on“, „off“ or „external“ (digital input) via PASO or via menu item.

Hint:

Digital input if not wired, the state of the digital input is not defined

CONNECTION EXAMPLES**Supply voltage****CAN connection****Digital input as function input****Digital input as USB interface**

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93